


## SPARE PARTS



Item	Part No.	Description
1	SP 170	Jet
2	SP 1500 C	Spark Plug
3	SP 1400 AC	Flame Supervision Device
4	SP 1400 BX	Hose Connector Assembly
5	SP 1400 BA	Thermocouple
6	SP 1400 BD	Igniter and Lead
3 & 5	SP 1400 BE	T'couple & Flame S'vision Device

Item	Part No.	Description